

PRODUCT SHEET



Biomeme

# Biomeme

# DNA/RNA M1

# Sample Prep

---

Last updated: 06/21/2021

Version 1.0



# Table of Contents

---

Brief Overview	3
Kit Contents	4
Technical Specifications	4
Sample Extraction Protocol	5
1. Sample Collection	5
2. ● Lysis & Binding (10 pumps)	6
3. ● Protein Wash (2 pumps)	6
4. ● Salt Wash (1 pump)	7
5. ● Drying Wash (1 pump)	7
6. ● Air Dry (20+ pumps)	8
7. ● Elution (5 pumps)	8
Disposal of M1 Sample Prep Cartridge	8
Storage	9
Disclaimer	9



## DNA/RNA M1 Sample Prep

---

The Biomeme DNA/RNA M1 Sample Prep Cartridge is a mobile solution for the extraction of purified nucleic acids from a variety of different sample types including but not limited to smaller volume liquids (e.g. whole blood) and direct swabs.

This kit requires no lab equipment, refrigeration, electricity, incubation, alcohol precipitation or phenol chloroform extraction. Instead, it utilizes a filtration-based method in which nucleic acids selectively bind to the silica membrane inside Biomeme's proprietary M1 Sample Prep Columns. Subsequent washes through a sequence of specially formulated buffers yields purified nucleic acids upon elution.

**Safety Warning:** When working with our products, always wear appropriate personal protective equipment (PPE) (e.g. lab coat, disposable gloves with adequate chemical resistance, mouth/face protection, goggles, etc.). For more information, please review the product's safety data sheet(s) (SDS).

## Kit Contents

ITEM	QUANTITY
DNA/RNA Cartridge containing Biomeme Lysis Buffer (BLB), Protein Wash (BPW), Wash Buffer (BWB), Drying Wash (BDW), and Elution Buffer (BEB)	96x
Single-use 1mL syringe	96x
Biomeme Sample Prep Column	96x

## Technical Specifications

SPECIFICATION	VALUE
Sample Amount	Varies by sample type
Processing	Manual
Elution Volume	0.85mL
Time Per Prep	2-5 minutes

# Sample Extraction Protocol

Samples are lysed by mixing in Biomeme Lysis Buffer (BLB). The lysed sample is then passed through the M1 Sample Prep Column by use of the provided 1 mL luer lock syringe, binding RNA to the silica membrane inside of the column.

Subsequent washes remove unwanted material and salts. Finally, purified nucleic acids are eluted off the column into the provided buffer.

Buffers come pre-aliquoted in the provided sample prep cartridges for ease-of-use and the extraction method is designed to be completed in a few simple steps. But, before beginning the sample extraction process, please take a moment to read these important tips:

- Clean your work area between each RNA extraction to avoid contamination between samples.
- Puncture 2 holes in each section of the M1 Sample Prep Cartridge as you move through each step to minimize liquid splatter (except Air Dry step).
- Pump slowly, except during the Air Dry step where rapid pumping is required, to not only minimize liquid splatter but to also improve binding to the sample prep column.
- **Note:** For additional tips, How-To videos, and best practices for our Sample Prep system, please visit our Biomeme Sample Prep Guide, available at: <https://help.biomeme.com/sample-prep-guide>

## 1. Sample Collection

1. Secure the Sample Prep Column to the 1mL syringe and puncture the first red hole of the Sample Prep Cartridge, labeled “START”. Set aside the syringe.

2. Add sample into the punctured hole.

*Note: The volume of sample required is user determined based on the relative abundance of target, sample type, and other factors.*

## 2. Lysis & Binding (10 pumps)

1. Place the syringe with the attached Sample Prep Column back into the red section of the Sample Prep Cartridge and draw Biomeme Lysis Buffer (BLB) fluid all the way up the syringe and pump all the way back out. Repeat for a total of 10 pumps.
2. Push all fluid in the syringe into the red section of the Sample Prep Cartridge prior to beginning the next step. Do not transfer any liquid from one section of the sample prep cartridge to the next. This applies to each remaining step of the sample extraction protocol.

*Note: If the column starts to clog, you will experience an increase in pressure. Do not press harder as this will cause additional clogging. Instead, remove the tip of the sample prep column from the red section of the sample prep cartridge and gently pull back the plunger, wait a few seconds, and slowly push the plunger back down. You should notice some of the liquid discharge at the open end of the syringe. Repeat this process until all liquid has been discharged from the column then proceed to the next step.*

## 3. Protein Wash (2 pumps)

1. Move the 1mL syringe with the attached Sample Prep Column into the red-orange section of the Sample Prep Cartridge (Biomeme Protein Wash -

BPW) and pierce through the foil. Remember to pierce 2 holes per section of the cartridge to minimize liquid splatter, except during the Air Dry step.

2. Draw the BPW fluid all the way up the syringe and pump all the way back out. Repeat twice assuring that no buffer remains in the syringe before beginning the next step.

#### **4. Salt Wash (1 pump)**

3. Move the 1mL syringe with the attached Sample Prep Column to the orange section of the Sample Prep Cartridge (Biomeme Wash Buffer - BWB) and pierce through the foil.
4. Draw the BWB fluid all the way up the syringe and pump all the way back out once assuring that no buffer remains in the syringe before beginning the next step.

#### **5. Drying Wash (1 pump)**

5. Move the 1mL syringe with the attached Sample Prep Column to the yellow section of the Sample Prep Cartridge (Biomeme Drying Wash - BDW) and pierce through the foil.
6. Draw the BDW fluid all the way up the syringe and pump all the way back out once assuring that no buffer remains in the syringe before beginning the next step.

## 6. Air Dry (20+ pumps)

1. Move the 1mL syringe with the attached Sample Prep Column to the blue section of the Sample Prep Cartridge and pierce through the foil to remove excess buffer.
2. Draw air up through the syringe and quickly pump back out. Repeat pumping vigorously 20 or more times until the Sample Prep Column appears dry and does not spray fluid droplets.

## 7. Elution (5 pumps)

3. Move the 1mL syringe with the attached Sample Prep Column to the green section of the Sample Prep Cartridge (Biomeme Elution Buffer - BEB) and pierce through the foil.
4. Elute by drawing the BEB fluid all the way up through the syringe and slowly pump back out for a total of 5 pumps.
5. That's it! Transfer 20µL of elution from the green section of the Sample Prep Cartridge into each of your PCR reactions.

*Note: If you wish to store your eluted DNA or RNA for later use, transfer all of the eluate to a clean microcentrifuge tube.*

## Disposal of M1 Sample Prep Cartridge

We recommend placing the absorbent material supplied in the sample prep pouch onto the top of the used cartridge and placing everything back into the open



pouch. These should then be placed into a separate larger sealed container or bag prior to disposal.

Always dispose of potentially biohazardous solutions according to your local, regional or national waste-disposal guidelines. DO NOT add bleach or acidic solutions directly to the buffers contained in Biomeme's M1 Sample Prep cartridges.

## Storage

All components of the Biomeme DNA/RNA M1 Sample Prep cartridge should be stored in a dry place, at room temperature (15-30°C).

## Disclaimer

**For Research Use Only.** Not for use in human or veterinary diagnostics. The performance characteristics of this product have not been established.

Biomeme products may not be transferred to third parties, resold, modified for resale or used to manufacture commercial products or to provide a service to third parties without written approval of Biomeme, Inc.

All warranties are subject to our [Terms and Conditions and Privacy Policy](https://biomeme.com/terms-and-conditions-and-privacy-policy) (<https://biomeme.com/privacy-policy-and-terms-of-use/>).

Biomeme, Inc.  
1015 Chestnut Street, Suite 1401  
Philadelphia, PA, USA 19107  
[support@biomeme.com](mailto:support@biomeme.com)

[Patent Protected](https://biomeme.com/patents/)  
(<https://biomeme.com/patents/>)